

# ***DOORGUARD VISITOR ENTRY SYSTEM***



## **USER OPERATING INSTRUCTIONS**

A DoorGuard Intercom System has been installed in your building to provide increased security for you and your visitors. The system provides communication and entry control using your telephone.

When you receive calls from the DoorGuard Intercom on your telephone, to permit entry dial the digit "9". To deny entry, simply hang up and do not dial "9".