

FINDING AND RECORDING EVIDENCE FROM WAVEREADER CREATING AN EVIDENCE CD OR A VIDEO CLIP ON YOUR PC

- Start WaveReader, log in to the application, and connect to the DVR you wish to record from.
- Go to the “Record” menu and select “Record Setup”. You will be asked to choose the directory or CD Writer you wish to store the file(s) on.
- After choosing a Directory, type in a file name. For most applications you will want JPEG2000 (.20D) output.
- View the video playback, setting the video to the beginning of the clip you wish to record, with the playback paused.
- Go to the “Record” menu and select “Start Recording”. Play back the video clip through to the end at the speed you desire. The resulting video clip will exactly copy all play speed and camera settings you choose.
- When complete click the “Record” menu and select “Stop Recording”.
- The file is now complete but you can add to it at any time by repeating the above process.

Note: Either WaveReader or the simple player version called QuickWave must be on a PC used to view the created CD or video clip. Our support page contains a link to the current version of WaveReader, the complete QuickWave application and documentation on how to use them.

COPYRIGHT © 2006, FITCH SURVEILLANCE SYSTEMS INC.

<http://www.fitch.ca>

For assistance with this or other issues, contact support@fitch.ca
or call 416-235-1818

